



# Fitting Instructions

TOWBAR C26  
For CITROEN XSARA ESTATE  
(1998-)

## MATERIALS

A	1	Main Frame with European facing to 94/20/EC – A50-1
C1	1	Left Hand Side Arm
C2	1	Right Hand Side Arm
D	2	M10 Nuts, Lock Washers and Flat Washers (25mm O.D)
D1	2	Spreader Plate (with Captive bolt)
E	2	M10 x 55mm Bolts, Nuts, Lock Washers and Flat Washers (25mm O.D)
E1	1	Spacer Plate
E2	2	25mm O.D. Bush 10mm long
F	2	M10 x 35mm Bolts, Nuts, Lock Washers and Flat Washers (25mm O.D)
G	2	M10 x 75mm Bolts, Nuts, Lock Washers and (6 off) Flat Washers (25mm O.D)
CB	2	M16 x 50mm Coupling Bolts, Nuts and Lock Washers

## FITTING

1. Loosely attach Main Frame (A) to holes provided in the rear cross frame (465mm centres) using Bolts (G) with flat washers (ensure Flat Washers at (X) are fitted between forward face of Main Frame (A) and rear cross frame).
2. Attach forward end of side arms (C1) and (C2) to holes provided in wheel arch frame using Nuts (D) with spreader Plates (D1) (remove nut to clean threads) inserted from above inside boot (remove plastic grommet in boot floor to reveal access hole - Note: the existing mounting is offset to the outside and is not visible from above). Attach Side arms (C1) and (C2) to Main Frame (A) and vehicle chassis at holes provided using Bolts (F) with Flat Washers, Spacer Plate (E1) fitted on the inboard face of the chassis and Bushes (E2) on the outside and Bolts (E) with Flat Washers.
3. Fully tighten all bolts starting with Bolts (G).

**Note:** This towbar must be used with either a Witter Towball (part number Z1) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

**Recommended torque settings:** M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

