



Fitting Instructions

TOWBAR DT101A
For NISSAN PATROL GR (Y61)
April 1998 -

MATERIALS

A	1	Cross Bar with European facing to 94/20/EC - A50-1
B	1	Couple Spacer (10mm thick)
C	2	Side Spacers
D	6	M12 x 140 Bolts, Nuts, lock Washers and 12 Large Flat Washers (30mm O.D.)
E	2	Spacer bushes
CB	2	M16 x 50mm Coupling Bolts, Nuts, Lock Washers

FITTING

1. Remove bumper ends, 4 screws on the mud flap edge, 1 in the mud guard and 1 plastic plug in the corner. 3 bolts on the lower edge, 1 screw on the top edge and disconnect the wiring loom.
2. Remove the bumper beam, 4 bolts in the towing eye and 4 bolts in the ends of the chassis.
3. Insert Spacer Bushes (E) into the open ends of the chassis
4. Loosely attach Cross Bar (A) to the holes in the vehicle chassis using the 4 forward Bolts (D) and Side Spacers (C) with Large Flat Washers on both sides.
5. Using the Cross Bar as a guide drill for the rear hole and attach using Bolt (D).
Finally tighten all bolts and replace bumper.

Note: This towbar must be used with either a Witter Towball (part number Z11 or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

