



Fitting Instructions

TOWBAR RN91
For RENAULT LAGUNA HATCH (2007-)
LAGUNA COUPE (2009-)

MATERIALS

A	1	Crossbar with European facing to 94/20/EC – A50-1
B	4	Chassis Rail Bush (19 mm OD & 63 mm Long)
D	2	Side arms
E	4	M10 x 100 mm Bolts x 1.5 mm Pitch, Flat Washers (40 mm OD) and Nyloc Nuts.
F	4	M10 x 40 mm Bolts x 1.5 mm Pitch, Flat Washers QTY 4 (25mm OD) and Nyloc Nuts
G	2	M12 x 100 Bolts 1.75 mm Pitch (Grade 10.9), and Nyloc Nuts.
CB	2	M16 x 45 mm Coupling Bolts, Nuts and Lock Washers
H	1	Safety Chain Bracket (ZEQ2)
J	1	Electrical Plate (ZEP 3)
ZF	1	Flange Neck (ZF2031A) with international facing to 94/20/EC A50-1
ZS	2	Spacers (ZSB1)

FITTING

No need to remove bumper

1. Remove Plastic under tray, by removing 4 clips and 4 screws attached to the bumper skirt.
2. Remove the plastic bungs protecting the chassis rails, 4 each side. On the left side, insert Bolt (E) with 40mm washer into Bush (B) and locate into chassis rail. Carry out same process on the remaining 3 holes.
3. Attach side arm (D) to chassis rail, and loosely secure with bolts (E) on both sides with washers and nyloc nuts
4. Attach Cross Bar (A), using Bolts (F) with Flat washers (25 mm) on the outside of parts (D).
5. On under tray cut as per diagram, and refit using existing fixings.
6. Attach the Flange Neck (ZF) using Spacers (ZS) and fixings (G). **Note:** When tightening the neck, ensure it is positioned in its upper and rearmost position to ensure maximum clearance and height. Also fit safety chain bracket (H)
7. **Tighten all Bolts.**

Note: This towbar must be used with either a Witter Towball (part number Z11) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M12-139Nm (grade 10.9) , M16 - 214 Nm



