



# Fitting Instructions

TOWBAR SK8  
For SKODA FELICIA PICKUP  
1996-

## MATERIALS

A	1	Cross Bar with international facing to ISO 3853 (BS AU114)
D	4	M10 x 50 x 1.5mm Bolts, Lock Washers and Flat Washers (30mm O.D.)
D1	4	Spreader Plates with captive nuts.
E1	2	Spreader Plates with captive bolts.
CB	2	M16 x 50 x 2.0mm Coupling Bolts, Nuts and Lock Washers

## FITTING

1. Remove spare wheel. Insert Spreader Plates (E1) through large holes on lower face of rear panel and align bolts with holes inboard of access holes. NOTE: Remove all mastic etc. from mounting surfaces and treat with anti-rust paint.
2. Loosely attach Cross Bar (A) to Spreader Plates (E1).
3. Insert Spreader Plates (D1) into frame from underside and attach to Cross Bar (A) using Bolts (D).  
NOTE: If mounting holes are not present use towbar as a guide, drill holes for Bolts (D). Beneath holes, on lower face of chassis make slots for Spreader Plates (D1).
4. Tighten all bolts. Re-mount spare wheel.

NOTE: It may be necessary to bend exhaust hanger slightly to gain extra clearance.

This towbar must be used with either a Witter Towball (part number Z1) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

**Recommended torque settings:** M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

