



Fitting Instructions

DETACHABLE TOWBAR VW55Q
For VW PASSAT

MATERIALS

A	1	Cross Bar
ZQ	1	ZQ3022 Detachable Unit
D	4	M12 x 40mm x 1.75 Bolts, Lock Washers and Flat Washers
EP	1	Electrical Plate (ZEP3)

FITTING

1. Remove bumper (4 screws around wheel arch, 1 tip screw, screws along lower edge and 2 beneath light clusters (remove light clusters). Pull bumper off sliders and disconnect number plate lights. Remove and discard bumper beam. **Refit bolts to rear panel to prevent ingress of water.**
2. Lower exhaust heat shield and remove plastic cover from right hand chassis rail. Remove tape covering mounting holes in outer face of chassis rails.
3. Cut bumper as shown below. Slide Cross Bar (A) into open ends of chassis and attach using bolts (D) with Flat Washers.
4. Please refer to ZQ fitting instruction for fitting of ZQ detachable unit.
5. Refit Bumper, exhaust heat shield etc.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

