



Fitting Instructions

TOWBAR VW9C
For VOLSWAGEN
TRANSPORTER/VAN/CARAVELL
FROM 1980- 1991

MATERIALS

A	1	Towbar Mainframe with European facing to ISO 3853 (BS AU114)
C	2	Side Arms (1 off each hand)
D	4	M12 X 40mm X 1.75mm Set Screws, Lock Washers and Flat Washers
E	2	M10 X 30mm X 1.5mm Bolts, Lock Washers and Flat Washers
G	2	Bumper Mounting Brackets (1 off each hand)
H	2	M8 X 12mm Bolts and Lock Washers
X	2	M8 Nuts and Lock Washers
CB	2	M16 x 50mm Coupling Bolts, Nuts, Lock Washers 200mm of Edging Strip

FITTING

1. Remove bumper from vehicle, remove and discard the bumper arms.
2. Plastic Bumper – Cut slot along etched lines in lower edge of bumper to allow towbar access. Attach Bumper Mounting Brackets (G) to Side Arms (C) using Bolts (H). Attach Mounting bracket and side arm assembly into plastic bumper. Using existing bumper mounting bolts and nuts provided (X). Tighten all bolts.
3. Steel and Plastic Bumpers – Position the Towbar (A) and Side Arms (C) inside the frame as diagram, align the forward holes (E) with the holes in the frame and loosely attach with washers under the bolt heads. Align and attach the Bolts (D).
4. Steel Bumper – Mark the position of the slot in the lower edge of the bumper and cut as required. Repaint the bare edge and fit the Edging Strip provided. Refit bumper.
5. Finally tighten all bolts.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

